

✓ **Know How to Measure Your Slider Windows for Window Guards:**  
Window Guards are installed vertically (bars go up and down)  
(Be sure children are not present when measuring window openings)



Measure from windowsill to inside top of window frame.



With window open: Measure window opening from inside jamb, right to left. (Usually screened area)



You can also measure and install the guards on the outside of the window casing as shown above.



Consider your window treatments when determining placement. Photo shows a close up of the top of the window. Guard is mounted inside, close to window; blind is installed on the outside casing.